


ogawa
by OGAWA

INIZIO

Fresh Start For Your Body



Rev.1.0

User Manual
YH-7236

Safety Instructions

Warning!

The plug must be fully inserted into an appropriate outlet. Improper connection of the equipment-grounding conductor can result in the risk of electric shock.

Check with a qualified electrician and service personnel if you are in doubt as to whether the product is properly grounded. Do not modify the product's accompanying plug. If the outlet is not suitable, be sure to have a proper outlet installed by a qualified electrician.




When using the massage chair, basic precautions should always be followed to reduce the risk of electric shock, burns, fire, or injury.

Read the following details before use:

1. Be sure to insert the massage chair plug into the proper electrical outlet.
2. Make sure that the power plug is securely inserted into the proper electrical outlet to reduce the risk of short-circuit and fire.
3. Always unplug the massage chair from the electrical outlet immediately after use and before cleaning.
4. DO NOT use the massage chair in places where the humidity is high.
5. DO NOT use the massage chair outdoors and avoid places with direct sunlight.
6. If the power goes off during use, be sure to turn the power switch to the OFF position and pull the power plug out from the socket to prevent any damages when the power comes back.
7. Never operate the massage chair if the power cord is wet or damaged.
8. Never plug/unplug the power cord from the socket with wet hands.
9. Close and continuous supervision is necessary when this appliance is used by or near children, invalids or disabled persons.
10. Use this appliance only as described in this user manual.
11. Do not use any attachments other than those recommended by ogawa.
12. Do not stand, sit or jump in the calves rest when the massage chair is in use. This may result in an accident or injury.
13. Do not attempt to stand on the backrest and armrest .This may result in an accident or injury.
14. Be careful not to fall asleep during the massage.

Safety Instructions

15. Always keep the massage chair clean and never insert any object into the gaps on and around the massage chair.
16. Do not remove the massage chair by pulling the power supply cord.
17. Be sure to check that there is no one (children in particular), pets or obstacles under the massage chair prior to lowering the leg rest /backrest.
18. Always check whether the surface of the massage chair is torn or ripped before use. If you find any unfamiliar tears in any area of the cloth in the backrest, do not use the massage chair. Kindly contact ogawa service center immediately for repairs.
19. This appliance is designed for household use only.
20. For those suffering from illnesses, please consult your doctor on whether you can use the massage chair if in doubt.
21. The following persons are requested to consult a doctor prior to use in order to reduce the risk of the user feeling sick or suffering from an injury:
 - Those who have a malignant tumor;
 - Those who suffer from heart disease;
 - Those who are experiencing pregnancy, menstruation and puerperal;
 - Those who require complete rest;
 - Those who are under medical treatment;
 - Those who suffer from back problems or whose backbone is abnormal or bent.
22. If you experience pain during use, stop the massage chair immediately. If any injuries happen, consult a doctor immediately. Never massage on swollen or inflamed parts of the body.
23. This product is a non-professional appliance designed to provide a comfortable massage. Do not use this product as a substitute for medical treatment.
24. Do not use this massage chair for more than 30 minutes at one time and kindly limit the massage to a concentrated area for not more than 15 minutes. Over-massaging can result in overheating, and thus reducing the product's lifespan.
25. Do not operate where aerosol (spray) products are used or where oxygen is being administered.
26. Children shall not play with the appliance.
Cleaning and user maintenance shall not be made by children without supervision.

- 
- 
- 
27. If the power plug is damaged, it must be replaced by a special plug available from ogawa or authorized agents.
28. As a safety precaution , Motor will stop working automatically (for protection) if apply too strong external force during use. Once appear above, switch OFF power ,and switch ON again after 10 seconds . Please pay attention to this ,especially for user whose weight over 100KG.
29. The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.
30. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved





Warranty Claims



1. Warranty is not transferable.
2. This warranty is effective only if the product is purchased from Ogawa.
3. Proof of purchase (original receipt) is required for all warranty repairs.
4. All implied warranties, including but not limited to these implied warranties of fitness and merchantability, are limited to the duration stated in the warranty policy.
5. Damage due to misuse, improper treatment and unauthorized modification and repair are not covered by this warranty.
6. Warranty does not cover accessories and attachments which do not belong to the massage unit.
7. Warranty is not effective to rental, business, commercial, institutional or other non-residential users.
8. All services covered by this warranty must be approved by ogawa and repaired by authorized technicians only.
9. If replacement parts for defective materials are not available, ogawa reserves the right to make substitution in lieu of repair or replacement.


Product Parts



Important: Product Image or content descriptions may differ due to product quality and feature improvements.


Moving the Chair

Press down the backrest, before reclining the chair to approximate 45° to easily move the chair around the house with a slight pull or push.




Warning

- i. Before moving the chair, please put the footrest back in the original position. Otherwise, injuries might occur in the process of moving the chair.
- ii. Avoid moving the massage chair when there is someone seated on it.
- iii. Placing a mat underneath the massage chair is advisable, as the moving process might leave scratches on the floor surface.

 **Warning:** Ensure continuous supervision and guidance is provided as necessary when massage chair is being used by small children, elderly and the disabled. Please take care as a massage chair is not a toy and have various moving parts that could cause severe injuries. The heat function that is present on this massage chair should not be used by those with sensitive skin issues as it may cause injuries such as burns and blisters.

Controller Diagram



Controller

① Monitor	⑧ Manual Massage	⑮ ZERO Gravity
② Work Relief Massage	⑨ Seat Upright	⑯ Heat Therapy
③ Recovery Massage	⑩ Seat Recline	⑰ Message Speed -
④ Sweet Dream Massage	⑪ On / Off	⑱ Message Speed +
⑤ Airbag Intensity +	⑫ Voice Command	⑲ Waist & Hips Massage
⑥ Airbag Intensity -	⑬ Foot Roller Activation	⑳ Neck & Shoulders Massage
⑦ Time Select	⑭ Airbag Selection	㉑ Spine Care Massage

Instructions of buttons

Warning: Only rated supply 220-240V~ must be used to avoid damage to electronic elements.


Product Operation Guide

1. Powering up the massage chair

Please make sure that the power switch at the back of the massage chair is in the off "O" position, then insert the power cable into the port to the left of the switch. Once firmly plugged in, proceed to plug the power cord into the outlet. Then put the switch to the on "I" and the remote should light up.

Powering down the massage chair

To shut down the massage chair, ensure that the chair is turned off using the Controller or Shortcut Keys by pressing and holding the "Power" button for 3 seconds and wait for massage chair to return to the upright position. Then, at the "ON/OFF" power switch, change to the "O" position to shut down and pull out power cord from massage chair and power outlet for safety purposes.



2. Starting your massage

Sit comfortably in the chair with your entire body pressed firmly against the backrest pad and place your feet snugly into the footrest to ensure a consistent and pleasant massage on your entire body. Then press the "On/Off" button for 3 seconds to power on the massage chair and select a massage mode to start.



On / Off



Press Time Setting button to adjust massage time. Maximum is 30 minutes.

3. Adjusting the angle of the recline

Please adjust the backrest and legrest angle prior to selecting a massage function. Getting into position before selecting the massage function allows for the chair to deliver a more accurate massage. The chair and legrest can be adjusted simultaneously or independently, depending on the button selected on the remote as illustrated below.

Press the "ZG" button to start zero gravity massage.

You may adjust the massage chair angle prior to selecting your desired massage mode or function.



Upright Position



Recline Position



Zero-G Position

4. Pausing a Massage Mode

The default timer for each massage program is pre-set at 15 minutes. You may select the "Timer" button to increase to 20 and maximum 30 Minutes respectively. When timer runs out, the program will stop and maintain the posture settings.



Product Operation Guide

5. Selecting a preset programmed massage

Automatic programs combine kneading and air massage.

Button	Description	Main function
	Work Relief message program	Press the button to start Work Relief massage. * This is an exclusive massage program for the workplace, it can ease muscles and recuperate body.
	Spine Care message program	Press the button to start Spine Care massage. * Mainly focus on your full back with a deep massage that includes air compression to relieve the lumbar spine pain.
	Neck & Shoulder message program	Press the button to start Neck & Shoulder massage. * Mainly focus on your neck and shoulders with a slow massage that incorporates soothing heat to relieve neck and back pain.
	Recovery message program	Press the button to start Recovery massage. * A full body deep massage includes shiatsu, knocking and tapping to ease and relax muscles.
	Sweet Dreams message program	Press the button to start Sweet Dreams massage. * A mild massage that is great for deep relaxation. The program help improve the quality of sleep.
	Waist & Hip message program	Press the button to start Waist & Hip massage. * A full body massage, mainly focus on your lower back, waist and hips with a deep massage that includes air compression to relieve lower back pain.

※ For above programs, the preset time is 15 minutes and the default of airbag intensity is low.

Press the “” 、 “” buttons to adjust the intensity of air pressure.


※ The above automatic full-body massage courses cannot be combined with other programs.

Product Operation Guide

Manual setting course

Introduction of manual setting course






Manual Massage function allows the user to precisely adjust the massage focus solely on a specific zone of the body. Press the "Mode" Button to cycle continuously through different regions of the back to be massaged.

Button	Target Areas	Roller
	Neck+Back	1+2
	Back+Waist	3+4
	Hip	5
	Whole back	1+2+3+4
	Whole back+Hip	1+2+3+4+5

※ The above manual setting course could not be combined with other courses.










※ The speed of the massage can be controlled by using the "Speed" buttons on the controller or turning the "Power" knob left or right to decrease or increase speed.

Function introduction for manual setting course

Button	Name	Description
	On / Off	Press this button to turn on/off the massage chair.
 	Airbag Intensity +	To adjust Airbag massage intensity while having a massage, press "Strength+" button to increase strength and press "Strength-" button to reduce strength until desired comfort is achieved.
	Airbag Intensity -	
 	Massage Speed +	To adjust Massage speed while having a massage, press "Speed+" button to increase strength and press "Speed-" button to reduce strength until desired comfort is achieved.
	Massage Speed -	

Product Operation Guide

Manual setting course

Button	Name	Description
	Seat Upright	Press the "Upright" button once to continuously recline. Press again to stop at the desired position.
	Seat Recline	Press the "Recline" button once to continuously recline. Press again to stop at the desired position.
	Heat Therapy	Press the "Heat" Button to enable/disable Heat Therapy while having a massage. Note: Heat Pads are located within the backrest Pad.
	Foot Roller Activation	Press the "Foot Roller" Button to enable/disable foot roller function during massage session.
	Airbag Selection	Press the "Airbag Select" Button to cycle through distinct airbag massage areas. Note: Airbag Massage area are: Shoulders, Arms, Waist, Legs.
	ZERO Gravity	Press the "Zero Gravity" Button to quickly move to preset Zero Gravity position.
	Time Select	Press the "Time" Button to cycle between default 15 minutes, to 20, 25 and 30 minutes. Note: Timer will reset to the selected time duration if selected while massage is ongoing.
	Voice Command	Press the "Voice Command" button to activate voice control manually if you do not wish to activate using voice command. Note: Press for 5 seconds to deactivate microphone for current session, press another 5 seconds to reactivate microphone. If microphone has been deactivated, the microphone will stay deactivated and will only reactivate after each restart and an audio prompt will sound to confirm microphone status.
	Child lock function	Long press the "Auto+Heating" shortcut button to activate the child lock function.

Music Function


Connecting your mobile device: Turn on Bluetooth functionality on your mobile phone or tablet, look for available devices and select the Bluetooth device with the code (YH-7236). After pairing with the Ogawa massage chair, you may now enjoy your favourite music or podcasts while enjoying the massage.

Cleaning And Maintenance

Cleaning of the synthetic leather


Wipe the synthetic leather with a soft dry cloth.

- **Do not clean the product with chemicals such as thinners, gasoline and alcohol.**
- **When using a leather maintenance product (cleaning cloth) sold on the market, follow its directions for use.**
- **If the synthetic leather is very dirty, wipe it with the method below.**
 1. Put a piece of soft cloth into water or 3% to 5% neutral detergent contained hot water and wring it out.
 2. Wipe surface of the synthetic leather with the soft cloth.
 3. Wipe the detergent with a piece of cloth once soaked in clean water and wrung out.
 4. Wipe with a piece of wrung soft cloth.
 5. Allow the synthetic leather to naturally air dry.
- **If it is difficult to remove the stains on the synthetic leather, soak a piece of melamine foam bought from the market into a neutral detergent and use it wipe the product.**
- **Do not dry the surface by a hair dryer**
- **Surface of the synthetic leather may be dyed by fabric colors; therefore, be careful when wiping the product with denim or colored cloth.**
- **Keep these positions from long-time contact with plastics to avoid fading.**
- **Synthetic leather may discolor, so the position in contact with the hair dye used should be covered by a towel.**



Cleaning of the plastic parts

- 1 Put a piece of soft cloth into water or neutral detergent contained hot water, wring it out and wipe the plastic parts.**
 - Do not clean the product with chemicals such as thinners, gasoline and alcohol.
- 2 Wipe with a piece of cloth once soaked in clean water and wrung out.**
 - Wring the cloth out before using it to wipe the remote controller.
- 3 Have the plastic parts take natural air drying.**



Questions and answers (Q&A)

Q Can persons paying frequent visits to hospitals because of diseases use the product?

A **These persons should consult physicians before using the product.**
 Massage is the so-called "touch-pressure stimulation": Muscles are compressed to relieve tension and promote blood circulation. However, certain medical conditions may worsen due to massage. Therefore, consult your attending physician before using the product.

Q How about the body height requirement for use of the product?

A **The body height requirement differs with the specific body type. See the rough reference below when using the product.**
 If a person shorter than 160 centimeters or taller than 180 centimeters and uses both the upper body massage function and the Lower Leg/Foot massage function of the product simultaneously. It may result in poor contact between their soles and the foot massage section or require them to bend their knees.

For a taller person with knee bending when using the product:

Select method **A**

A Tilt the backrest and lower the Lower Leg/Foot massage section.

For a short person difficult to touch the foot massage section:

Select method **A**

A Raise the backrest and lift the Lower Leg/Foot massage section.


Q Are there any things needing special attention during moving?

A **Pay attention to the following things during moving.**

For convenience during moving, tilt backrest of the product till the lowest position.

During handling, do not sit on the product.

① Press ON button power on the product.

② Press  to make the backrest completely tilt.

Press and hold on these two buttons until backrest and footrest stop



③ Turn off the power switch and pull out the power plug.


● If the original packing box is unavailable, make sure the power line is not wound on the product, wind it and place it on the seat surface. When handling the product, keep the power line from falling off and rubbing with ground.

● If the original packing box is unavailable, properly keep other packing auxiliary materials and wrap the product with them to avoid scratch and vibration during handling.

Q Where is serial number of the product?

A It is on back of the main body.

Serial Number



Q I care about the sounds the product makes when being used.

A It is caused by the core structure.

Q Does it matter if the massage wheels have different massage intensities?

A **This phenomenon possibly exists during massage because of the core structure.**

To simulate the most natural massage effect, the product is designed with a core structure allowing alternate back massage by a left massage wheel and a right massage wheel. During massage, the massage wheels possibly have slightly different positions on the back. That's why you have that feeling. It is not a fault.

Q The acupressure force is too large.

A **Set the air bag intensity to be "1" through the Air Bag button. You can also lower the Lower Leg/Foot massage section to reduce the acupressure force on the feet.**

Troubleshooting

After a fault happens, inspect and try the corresponding method below.

If the fault still exists after that, contact the shop from which you bought the product.


Fault	Cause and elimination method
The massage wheels stop during use (The product beeps and all icons and buttons on the remote controller flicker and then go out.)	<u>For safety, the massage wheels will possibly stop upon a too large external force during use.</u> If all marks and buttons on the remote controller begin to flicker, it suggests an extreme abnormality. In this case, turn off the power switch and turn it on about 10 seconds later. If the massage wheels stop again, adjust your sitting posture and do not lean on the backrest completely. (Users, particularly those heavier than 100 kilograms, should follow relevant precautions.)
The product cannot tilt, or the footrest cannot be raised or lowered (The product beeps, the running light on the remote controller goes out and the product stops)	<u>For safety, the product will stop upon an obstruction or a too large force.</u> If all contents and buttons are flickering and the backrest or the footrest has stopped, turn off the power supply and turn it on about 10 seconds later and then operate the product.
The massage wheels cannot reach the shoulders or the neck	If the head is not in contact with the headrest, or the back is not in contact with the backrest, the shoulder position in body type detection will possibly be lower than the actual position. Sit in the deepest position of the product, lean your head on the headrest and operate from the beginning again.
The left and right massage wheels have different heights (intensities)	It is not a fault but a normal phenomenon because the product is provided with a massage core allowing alternate beats of the massage wheels.
The product cannot run at all. ● Upper body (the neck to the waist) massage ● Lower leg/foot massage	<ul style="list-style-type: none"> ● The power line is disconnected. ● The power switch is not turned on. ● No program is selected after (⏻) on the remote controller is pressed.
The product cannot cool down even if the heating function is disabled.	<ul style="list-style-type: none"> ● Due to the heater structure, the product will still feel warm shortly after heating because of the residual heat. ● If a single part is continually massaged even after the heating function is disabled, you will feel increasingly warmer.
The power supply cannot be connected even if (⏻) is pressed again after the massage	<ul style="list-style-type: none"> ● The program will terminate about 5 seconds after the massage has ended. Press (⏻) at least 5 seconds after all the movements have stopped.
The product is damaged	To avoid accidents, contact an authorized service center.
The power line or the power plug has abnormal heating	

Troubleshooting

The sounds and feelings you care about in use of the product

You will hear or have the following sounds or feelings when using the product. It is not abnormal phenomena but results of the product structure.

- Sound when the stretching massages are retracted
- Sound and feeling when the massage wheels rub patterns on the fabric
- Sound of movements such as kneading and beat
- Friction sound of the running massage wheels
- Sound of up-down movement
- Sound of the conveyor belt
- Motor sound
- Sound of the squeezing massage wheels when they begin to stretch
- Sound when a person is sitting on the seat
- Friction sound between the armrests and the back cushion when the backrest is tilting
- Friction sound between the massage wheels and the fabric
- Sound of the inflator pump during Air Bag massage
- Sound of air exhaust during Air Bag massage
- Running sound of the solenoid valve at bottom of the product during Air Bag massage.
- Swing of the footrest
- Sound when the shoulders are stretched or moved
- Running sound of the air bags
- Sliding sound of the foot massage section
- Friction sound between the back cushion and the back cover leather when the backrest is tilting



If the sound is loud, it is also possible that the product has failed.

- In this case, have the product inspected and repaired by an authorized service center.

Warning

- **Do not refit, disassemble or repair the product without permission.** Otherwise fires, abnormal movements or personal injuries may happen.

Warning

- **In the case of any abnormality or fault, stop the product immediately and pull out the power plug to avoid fuming, fires and electric shocks.**
 - < Abnormality and fault examples >
 - The product fails to work after the power switch is turned to the ON position;
 - After the power line is moved, the product is discontinuously powered on;
 - In use, the product gives off a burning smell or an abnormal sound;
 - The product is deformed or abnormally heating
- In any of these abnormalities and faults, have the product inspected and repaired by an authorized service center immediately.

Product Specifications

Power supply		AC220-240V~,50/60Hz
Power consumption		90W
Adjust angle		Backrest: Approx. 130°~150° Footrest: Approx. 95°~140°
Automatic power-off		Approx. 15 minutes(automatic power-off)
Dimension	When it is not tilting (L x W x H)	Approx. 1430 x 735 x 1020 mm
	When it is tilting (L x W x H)	Approx. 1690 x 735 x 830 mm
Weight		Approx. 55 Kg
Dimensions of packing box (L x W x H)		1260x760x1060mm
Weight(including the packing box)		Approx. 65 Kg
Operating Conditions		Ambient temperature:Approx.0°C~35°C Relative humidity:Approx.20%~80%
Storage Conditions		Ambient temperature:Approx.-5°C~35°C Relative humidity:Approx.20%~80%
Maximum body weight of user		Approx. 120Kg

For a user heavier than 100 kilograms, the product may have bigger noise and its fabric housing may be worn quicker.

Voice Input Table

Voice Password	Response	Voice Password	Response
Hello, Massage	I am here	Massage mode	Massage mode is on
Power on	Massage starts	Sole kneading	Sole kneading
Shut down	Massage ends	Heating on	Heating on
Fully automatic	Fully automatic is on	Back up	Back up
Airbag automatic	Airbag automatic is on	Back down	Back down
Shoulder airbag	Shoulder airbag is on	Zero gravity	Zero Gravity mode
Arm hip airbag	Arm hip airbag is on	Hip massage	Hip massage
Leg airbag	Leg airbag is on	Increase time	Increase time
Kneading mode	Kneading mode is on		

安全說明

警告!

此按摩椅必須使用與插頭相配的插座。不正確的接地將會導致觸電危險的發生。

請不要擅自改裝插頭或插座，務必委託專業的技術人員進行檢查。

使用電器產品時，為減少觸電、灼傷、火災、或人員傷害的危險，應遵守基本安全預防措施，包括以下內容：

在使用前請閱讀所有的使用說明。

1. 務必使用與插頭相配的插座。
2. 一定要確保插頭完全插入插座內，以減少短路或火災危險。
3. 在使用後或清潔前，請務必及時拔掉插頭。
4. 請勿在高濕度的環境下使用本產品。
5. 請勿在室外或陽光直射的地方存放或使用本產品。
6. 如果在使用過程中突然停電，請立即將開關撥至「O」的位置，且拔掉插頭，以免來電時損壞本產品。
7. 當電源線潮濕或損壞時請勿使用按摩椅。
8. 請勿用濕手插入和拔掉插座，以免發生意外。
9. 當小孩、傷殘人士、行動不便者在按摩椅附近或使用按摩椅時，一定要有人在場看護。
10. 只能將本產品用於本說明書中闡述的用途。
11. 不要使用非Ogawa推薦的附件。
12. 在使用過程中請勿坐在按摩椅小腿上，以免導致意外。
13. 請勿試圖站在扶手或靠背上，以免按摩椅發生傾倒從而導致意外。
14. 按摩過程中請勿進入睡眠狀態。
15. 請經常保持按摩椅清潔，避免將其他物體插入按摩椅的縫隙中。
16. 請勿直接透過拉扯電源線來移動按摩椅。
17. 請確保當降低小腿或靠背時，其下方無其他物體，特別是小孩。
18. 請在每次使用前，檢查按摩椅靠背絨布等處是否有異常裂縫。如有異常，請勿使用並即時聯繫ogawa售後服務中心。
19. 本產品僅為居家使用而設計。
20. 當您無法確定自己是否能使用按摩椅時，請先諮詢醫師。

安全說明

21. 為避免因使用此按摩椅而導致不適或傷害，以下人士在使用本產品前應諮詢醫師：
- 患有惡性腫瘤者
 - 患有心臟病者
 - 孕婦、產婦或月經期者
 - 需要安靜休息者
 - 正在接受治療者
 - 有背部疾病者，脊椎異常或扭曲者
22. 如在使用過程中覺得疼痛，請立即停止使用；如果在使用過程中受到損傷，請立即就醫。
23. 本產品僅為家庭提供舒適的按摩享受，並非專業的按摩醫療機械，因此不能代替專業的治療。
24. 建議每天使用按摩椅的時間為 30 分鐘，按摩同一部位時間不宜超過15分鐘，否則過度按摩會導致適得其反的效果，而且長時間使用會導致按摩椅過熱並縮短產品使用壽命。
25. 請勿在噴氣體溶膠或輸氧的環境中使用本產品。
26. 12歲或以下兒童不適宜使用本產品。
27. 如果電源線損壞，必須使用ogawa或合法代理商所提供的專用電源線。
28. 使用過程中若施加過大的外力，為安全起見，機芯會自動停止以保護。當出現該情況時，先切斷整機電源，10秒后再接通電源進行操作。特別是體重超過100KG的用戶，使用時要特別注意。
29. 該設備具有加熱表面，對熱不敏感的人一定要小心使用設備
30. 此器械不適合身體機能減退的人（包括兒童）使用，感官或心智能力，或缺乏經驗和知識，除非他們已經由負責人提供有關設備使用的監督或指示他們的安全。應該監督孩子，確保他們不玩電器。

保修權限

1. 本保修權限不可轉讓。
2. 本保修服務僅對在ogawa購買的產品有效。
3. 當要求保修服務時，請出示購買證明（正本收據）。
4. 所有保修項目，包括但不限於這些健身及適銷性的保修項目有效期限需視保修政策而定。
5. 因錯誤使用、處理不當以及未經授權私自改裝和維修產品而導致的損壞，不屬於保修範圍。
6. 此保修範圍不包括不屬於產品本身的附件。
7. 此保修範圍不適用於租憑、交易、商業、機構或其他非住宅用戶。
8. 此保修範圍內所涉及的維修服務需經過ogawa授權，且必須由授權的技術人員維修。
9. 若需更換的維修附件缺貨，ogawa有權採用替代配件進行維修。

功能特點



ogawa按摩椅通過電腦智能化控制，配合揉捏、瑞典式、捶打、指壓、拍打、推拿，腳滾和氣壓功能等多種按摩手法及組合，針對各個穴位進行按摩，有效舒緩疲勞，促進新成代謝及加強血液循環。

具備各種全身自動/手動按摩功能以符合您的各種要求。

除了精確的穴位按摩外，可同步進行各種按摩功能以形成特制按摩程序。

1. 根據人體工學設計，以提供更有效的按摩效果。
2. 定時功能將按照你的需求對按摩時間進行調整。
3. 液晶顯示使手控器更易于操作。
4. 具備過熱過流保護，更加安全。
5. 操作是由微型智能處理器控制，使性能始終如一，卓越有效。
6. 本產品配有加熱功能，對熱不敏感者慎用。


產品部件



重要提示：由于產品質量和功能的改進，產品圖像或內容描述可能會有所不同。

產品移動說明

向下壓靠背，將靠背傾斜約45度以方便在室內自由移動按摩椅。




注意：

- i. 在移動按摩椅時一定要把腿墊完全收回，若不遵守，在移動過程中腿墊收到原始位置時，有可能導致受傷的情況。
- ii. 當有人坐在按摩椅上時，請不要移動椅子。
- iii. 移動按摩椅時可能會損傷地板，建議在本產品下鋪上墊子等。

⚠ 注意： 本產品不打算由肢體不全、感官或精神上有障礙或缺乏相關經驗和知識的人（包括兒童）使用，除非有負責他們安全的人對他們使用本產品進行監督和指導。應照看好兒童，確保他們不玩耍本產品。器具具有發熱表面，對熱不敏感的人使用時必須注意。

控制器



控制器

① 液晶屏幕	⑧ 手動按摩	⑮ 零重力
② 工作緩解按摩	⑨ 座椅豎立	⑯ 加熱療法
③ 恢復按摩	⑩ 座椅傾斜	⑰ 按摩速度-
④ 甜夢按摩	⑪ 開 / 關	⑱ 按摩速度+
⑤ 氣囊強度+	⑫ 語音命令	⑲ 腰部和臀部按摩
⑥ 氣囊強度-	⑬ 足部滾輪激活	⑳ 頸部和肩部
⑦ 時間選擇	⑭ 氣囊選擇	㉑ 脊柱護理按摩


按鈕操作說明

⚠ 請注意本機使用220-240V~電壓，使用其它電壓將可能造成內部電子零件損壞。

操作說明

1. 打開按摩椅的電源

- 請確保按摩椅后面的電源開關處於關閉“O”狀態，然後將電源線插入開關左側的插口。一旦牢固插好，然後將電源線插入插座。然後將開關切換到開啟“I”，遙控器應該亮起。要關閉按摩椅，請確保使用控制器或快捷鍵將椅子關閉，按住“電源”按鈕3秒鐘，等待按摩椅返回到豎立位置。然後，在“ON/OFF”電源開關上，切換到關閉“O”位置以關閉電源，並從按摩椅和電源插座上拔下電源線以確保安全。



2. 開始按摩

- 請舒適地坐在椅子上，將整個身體牢牢地壓在背靠墊上，將雙腳緊緊放在腳墊上，以確保全身獲得一致而愉快的按摩。然後按住“開/關”按鈕3秒鐘以啟動按摩椅，選擇一個按摩模式開始。




開 / 關



按下時間設置按鈕來調整按摩時間。
最長為30分鐘。

3. 調整傾斜角度

- 請在選擇按摩功能之前調整靠背和腿部扶手的角度。在選擇按摩功能之前調整位置可以讓椅子提供更準確的按摩。椅子和腿部扶手可以同時或獨立調整，具體取決於遙控器上選擇的按鈕，如下所示。
- 按下「」按鈕啟動零重力按摩。



豎立位置



傾斜位置



零重力位置

4. 暫停按摩模式

每個按摩程序的默認計時器預設為15分鐘。您可以選擇“定時器”按鈕，分別增加到20和最多30分鐘。當計時器用盡時，程序將停止並保持姿勢設置。


操作說明

5. 選擇預設程序按摩

自動程序結合揉捏和氣壓按摩。

按 鍵	名 稱	主要功能
	工作緩解按摩程序	按下按鈕啟動工作緩解按摩。 *這是一個專為工作場所設計的按摩程序，可以緩解肌肉疲勞和恢復身體。
	甜夢按摩程序	按兩次按鈕即可享受甜夢按摩。 *一種溫和的按摩，非常適合深度放鬆。該程序有助於提高睡眠質量。
	康復按摩程序	按三次按鈕開始康復按摩。 *全身深層按摩包括指壓、敲擊和輕拍，有助於舒緩和放鬆肌肉。
	頸肩部按摩程序	按四次按鈕開始頸部和肩部按摩。 *主要集中在您的頸部和肩部進行緩慢按摩，加入舒緩的熱量以緩解頸部和背部疼痛。
	脊柱護理按摩程序	按五次按鈕開始脊柱護理按摩。 *主要集中在您的整個背部進行深層按摩，包括氣壓按摩以緩解腰椎疼痛。
	腰臀部按摩程序	按六次按鈕開始腰部和臀部按摩。 *全身按摩，主要集中在您的腰部、臀部進行深層按摩，包括氣壓按摩以緩解腰部疼痛。

*以上程序的預設時間為15分鐘，氣袋強度默認為低。

*按下 “” 按鈕來調整氣壓強度。


*以上自動全身按摩課程無法與其他程序同時使用。

操作說明

手動按摩程式

手動按摩程式介紹






手動按摩功能允許用戶精確調整按摩焦點，只在身體的特定區域進行按摩。按下"模式(Mode)"按鈕，連續循環瀏覽不同要按摩的背部區域。

按 鍵	按摩區域	滾輪
	頸部+背部	1+2
	背部+腰部	3+4
	臀部	5
	整個背部	1+2+3+4
	整個背部+臀部	1+2+3+4+5

*以上手動設置課程不能與其他課程結合使用。










*按摩的速度可以通過使用控制器上的"速度"("Speed")按鈕或將"電源"("Power")旋鈕左右轉動來控制，以減小或增加速度。

手動設置程式介紹

按 鍵	名 稱	主 要 功 能
	開 / 關	按此鍵開啟或關閉按摩椅。
 	氣囊強度 +	在進行按摩時調整按摩速度，按下"速度+"("Strength+")按鈕增加速度，按下"速度-"("Strength-")按鈕減小速度，直到達到所需的舒適度。
	氣囊強度 -	
 	按摩速度+	在進行按摩時調整按摩速度，按下"速度+"("Speed+")按鈕增加速度，按下"速度-"("Speed-")按鈕減小速度，直到達到所需的舒適度。
	按摩速度-	

操作說明

手動設置程式

按 鍵	名 稱	主 要 功 能
	座椅豎立	按一次"豎立"("Upright")按鈕以持續傾斜。再次按下以停止在所需位置。
	座椅傾斜	按一次"傾斜"(Recline)按鈕以持續傾斜。再次按下以停止在所需位置。
	熱療	在按摩時按下"熱"("Heat")按鈕以啟用/禁用熱療。注意：熱墊位于靠背墊內。
	足底滾輪激活	在按摩過程中按下"足底滾輪"(Foot Roller)按鈕以啟用/禁用足底滾輪功能。
	氣囊選擇	按下"氣囊選擇"(Airbag Select)按鈕以循環瀏覽不同的氣囊按摩區域。注意：氣囊按摩區域包括：肩部、手臂、腰部、腿部。
	零重力	按下"零重力"(Zero Gravity)按鈕以快速移動到當前的零重力位置。
	時間選擇	按下"時間"(Time)按鈕以在默認的15分鐘、20分鐘、25分鐘和30分鐘之間循環選擇。注意：如果在按摩進行中選擇，計時器將重置為所選的時間持續時間。
	語音命令	按下"語音命令"按鈕以手動激活語音控制，如果您不想使用語音命令來激活。注意：長按5秒以取消當前會話的麥克風，再次長按5秒以重新激活已取消的麥克風，麥克風將保持取消狀態，僅在每次重新啟動后重新激活，並會發出音頻提示以確認麥克風狀態。
	兒童鎖定功能	長按"自動+加熱"快捷按鈕以激活兒童鎖定功能。

音樂功能

連接您的移動設備：打開您手機或平板電腦上的藍牙功能，搜索可用設備并選擇帶有代碼（YH-7236）的藍牙設備。配對成功后，您可以在享受按摩的同時欣賞您最喜歡的音樂或播客。

清洗及保養

清潔合成皮革

使用柔軟的干布擦拭皮革。

- 切勿使用諸如稀釋劑、汽油、酒精等化學品清潔本機。
- 使用市面銷售的皮革保養品（抹布）時，請遵照其使用說明。
- 如果合成皮革特別髒，則通過以下方式擦拭。
 - 1、將軟布浸入水中或含3%至5%中性洗滌劑的熱水中，然後徹底擰干。
 - 2、使用上述軟布擦拭皮革表面。
 - 3、使用浸過清水且已徹底擰干的布料擦掉清潔液。
 - 4、使用擰干的軟布擦拭。
 - 5、使其自然風干。
- 難以去除污漬時，請將在市面上購買的三聚氰胺泡棉進入中性洗滌劑中，然後用它擦拭本機。
- 不要使用吹風機吹干表面。
- 由於布料的顏色會染到合成皮革的表面上，因此在使用牛仔布和彩色布料擦拭本機時務必小心。
- 不要使這些部件長時間與塑料接觸，因為這會導致褪色。
- 合成皮革有變色的可能，所以在使用染發劑時，請將接觸的部分用毛巾覆蓋。




1 將軟布浸入水中或含有中性洗滌劑的熱水中，擰干后，擦拭本機塑料部。

- 切勿使用諸如稀釋劑、汽油、酒精等化學品清潔本機。

2 使用浸有清水且已徹底擰干的布料擦拭。

- 擦拭遙控器前請務必擰干布料。

3 使其自然風干。



疑問解答 (Q&A)

Q 因為生病而經常出入醫生的人可以使用本產品嗎？

A 經常出入醫院的人，請在醫生商量的前提下使用本產品。

按摩即所謂「觸壓刺激」，即通過對肌肉進行壓迫，緩解肌肉緊張，促進血液流動。根據不同的病因，按摩有可能造成病情惡化，因此請務必在和主治醫生商量之後使用本產品。

Q 身高多少的人適合使用本產品？

A 根據體型的不同多少會有所差異。請大致參考下文使用產品。

- 身高小於145cm的用戶，及身高超過185cm的用戶同時使用上半身按摩和小腿、腳部按摩時，可能出現足底與腳部按摩部接觸不充分，或膝蓋彎曲的情況。

身高較高的用戶感覺膝蓋部位彎曲時

請選擇下述方法 **A**

- A** 放倒靠背，降低小腿、腳部按摩部位置。

身高較矮的用戶難以向下觸到足底按摩部時

請選擇下述方法 **A**


- A** 抬起靠背，升高小腿、腳部按摩部位置。

Q 搬家時，有什麼需要特別注意的地方？

A 請注意一下事項。

- 為了方便搬運，請先將按摩椅靠背傾斜到最低位置。
- 搬運時，人不要坐在座椅上。

① 按下開機鍵，接通電源。


② 按下  使靠背呈完全傾斜狀態。

請長按這個按鈕，直到靠背和小腿停止移動。

- 在有原裝紙箱的情況下，請先確認電源線未被纏繞在本機上，將電源線纏好放在座面上；搬運的時候，請注意電源線沒有掉落且未與地面發生摩擦。
- 在沒有原裝紙箱的情況下，為了防止機體劃傷和搬運中的震動，請妥善使用其他包裝輔材包裹本品。

Q 請問在哪里可以看到產品序列號？

A 在按摩椅主體背面的座面下。



Q 有點在意按摩椅運作時發出的聲音……

A 按摩椅運作時產生的聲音，一般是由於機芯構造而發出來的。

Q 按摩中感覺左右兩邊按摩輪的按摩力度有差異，要緊嗎？

A 由於機芯構造，在按摩過程中，確有可能感覺左右按摩輪的力度有差異。

為了能夠模擬出最自然的按摩手法，本品機芯採用了允許左右按摩輪交替捶背的機芯構造。在按摩過程中，左右按摩輪接觸背部的具體位置可能稍有差異，從而導致了使用者產生左右兩側按摩力度有所不同的感覺。此時，本品本身並未發生故障。

Q 感到足底指壓過於用力……

A 使用氣囊按鈕將氣囊強度設置為「1」。另外，降低小腿、腳部按摩部，也可以減輕足底的指壓力度。

故障維修

發現故障后，首先檢查并嘗試一下方法。

如果在嘗試后，故障依然存在，請聯系銷售店。


問題	原因和處理方法
本使用本機過程中按摩輪停止 (按摩椅發出「嗶嗶」的聲音，遙控器上所有的顯示圖標和按鈕閃爍然后熄滅)	<p>在使用過程中，按摩輪遇到過大的外力時，處于安全考慮，按摩輪可能會停止移動。</p> <p>如果遙控器上的所有標記和按鈕開始閃爍，這種情況極為異常，請關閉電源開關，等待約10秒鐘，然後再次打開電源。 如果按摩輪再次停止，請調整自己的坐姿，不要使背部完全貼在靠背上。（應注意遵守相關注意事項，尤其在體重為100kg或以上的人使用時。）</p>
不能傾斜 腿置臺不能升高降低 (發出「嗶嗶」的聲音，遙控器的運行指示燈熄滅并停止運行)	<p>如果本機遇到了障礙物或者在使用本機時用力過大，處于安全考慮，本機將停止工作。</p> <p>當所有顯示的內容及按鈕在閃爍時，且靠背或腿置臺已停止工作，關閉本機電源一次，約10秒鐘后再次打「開啓」電源，然後操作本機。</p>
按摩輪沒有達到肩部或頸部的 位置	<p>如果頭部沒有接觸到靠枕，或背部沒有接觸到靠背，在體型檢測過程中肩部位置可能低於實際位置。坐在座椅的最深位置，將頭部靠在靠枕上，然後從頭開始重新操作。</p>
左右按摩輪的蓋度（強度） 不同	<p>因為搭載了可進行按摩輪交互捶拍動作的按摩機芯，出現這種情況純屬自然，并非機體故障。</p>
本機根本無法運行。 ● 上半身（頸部至腰部）按摩 ● 小腿和腳部按摩	<ul style="list-style-type: none"> ● 電源線連接已斷開。 ● 沒有打開本機電源開關。 ● 按下遙控器上的  按鈕后，沒有選擇任何程序。
即使關閉溫熱功能，溫度 也降不下來	<ul style="list-style-type: none"> ● 由于加熱器的結構，加熱后片刻依然會因為余熱而感到溫暖。 ● 關閉溫感功能，持續按摩同一部位，也會使體感溫度上升。
按摩結束後，即使重新按下  按鈕，也無法接通電源	<ul style="list-style-type: none"> ● 按摩結束後大約需要5秒鐘程序才終止。當所有運作均已停止后至少等待5秒鐘，然後再按  。
本機已受損	<p>為防止事故發生，請務必與授權服務中心聯系。</p>
電源線或電源插頭異常發熱	

故障維修

關於運行過程中本機發出的聲音和令人在意的感覺

在使用中會發生下述動作音、感覺，不過這是因按摩椅的結構而發生，并非異常。

- 按摩輪由「伸出」改為「收回」時的聲音
- 動作時按摩輪擦過面料上的皺紋時發出的聲音和感覺
- 揉按、捶拍動作等的動作音
- 按摩輪動作時的摩擦聲
- 上下運動時的動作音
- 傳送帶的轉動音
- 電機音
- 按摩輪從「擠壓」改為「拉伸」時的聲音
- 落座時的聲音
- 靠背傾斜時扶手與靠墊的摩擦聲
- 按摩輪與布料的摩擦聲
- 氣囊按摩運作時的充氣泵工作音
- 氣囊按摩運作時的排氣音
- 氣囊按摩運作時座椅下電磁閥發出的工作音
- 腿置臺的晃動
- 肩部伸展、動作時的聲音
- 氣囊的動作音
- 腳部按摩的滑動音
- 靠背傾斜時，靠墊與后蓋上皮革摩擦時發出的聲音



當聲音變大時，也有可能發生了故障。

- 此時，請委托授權服務中心進行檢查和修理。

警告

- 請勿擅自改造本機。請勿自行分解或修理本機。否則可能導致起火、異常動作、人身傷害。

警告

- 發生異常、故障時，立即停止使用，拔掉電源插頭。（否則可能冒煙、起火、觸電）
<異常、故障事例>
 - 接通電源開關后可能不動作
 - 移動電源綫，有時通電有時不通電
 - 運行中發出焦臭味、異常聲響
 - 按摩椅變形或者異常發熱→ 請立即委托授權服務中心檢查和修理。

產品規格

電 源		AC220-240V~，50-60Hz
消 耗 電 力		90W
傾 斜 角 度		靠背:約 130°~150° 小腿:約 95°~140°
自 動 關 閉		約15分鐘(自動斷電)
尺 寸	未傾斜時 (高 x 寬 x 長)	約 1430 x 735 x 1020 mm
	傾斜時 (高 x 寬 x 長)	約 1690 x 735 x 830 mm
重 量		約55 Kg
包裝箱尺寸 (長 x 寬 x 高)		1260x760x1060mm
重量(含包裝箱)		約65Kg
使 用 環 境		環境溫度:0°C~35°C 相對濕度:20%~80%
儲 存 環 境		環境溫度:-5°C~35°C 相對濕度:20%~80%
用戶最大體重		約120Kg

對於體重100kg或以上的人士，產品運作時可能產生更大的噪音而且面料外罩可能磨損得更快。

語音輸入表

語音密碼	回應	語音密碼	回應
Hello, Massage	I am here	Massage mode	Massage mode is on
Power on	Massage starts	Sole kneading	Sole kneading
Shut down	Massage ends	Heating on	Heating on
Fully automatic	Fully automatic is on	Back up	Back up
Airbag automatic	Airbag automatic is on	Back down	Back down
Shoulder airbag	Shoulder airbag is on	Zero gravity	Zero Gravity mode
Arm hip airbag	Arm hip airbag is on	Hip massage	Hip massage
Leg airbag	Leg airbag is on	Increase time	Increase time
Kneading mode	Kneading mode is on		

