




OGAWA

REJOY

F O O T M A S S A G E R



User Manual
OF1733 使用手册



OGAWA

REJOY

FOOT MASSAGER



User Manual

All information is correct at the time of print



CONTENTS

| | |
|--|----|
| Safety Instructions | 03 |
| Warranty Claims | 06 |
| Product Parts | 07 |
| Product Features And Operation Illustrations | 08 |
| Product Operation Guide | 09 |
| Product Maintenance | 10 |
| Troubleshooting | 11 |
| Product Specifications | 12 |
| Contact Us | 13 |



Thank you for purchasing OGAWA massager.
Please read the Safety Precautions carefully before using the leg massager. The Safety Precautions are divided into 'warnings' and 'attention' in terms of the degree of danger. This book should be kept available for future reference after reading.



Safety Instructions

a) Important safety instructions

- To ensure a safe and proper operation, please read the instruction manual carefully before using this product.
- Use this product only as described in this manual.
- Always unplug this product from the electrical outlet immediately before cleaning.
- Do not use this product if you have sensitive skin, neuropathy
Don't let children or people with mental disabilities use the heating function without proper supervision. Improper use may be dangerous.
- Do not operate this product under a blanket or when covered. Over-heating can occur and cause fire, electric shock or injury.
- Do not cover this product in order to avoid electrical faults or damages due to excessively high motor temperature.
- Stop the massage immediately if you feel any discomfort.
- Never operate this product if it has been dropped, has a damaged cord or plug; experiences a malfunction, or if it has been dropped in water. Please contact an authorized service centre to do the necessary check and repair.
- Do not use the components that are not recommended by OGAWA.
- Do not insert any objects into any openings in the product.
- If you want to cut off the power supply, please make sure you have turned off all the operating controls, as well as remove the power plug from the socket.
- Please do not use this product as a medical device. If you need a professional diagnosis or treatment, please consult a professional medical person.

b) Operating Environment Precautions

- Do not use this massager in humid or extremely dusty environments to avoid malfunction.
- Do not use this massager at a temperature above 40 degree centigrade.
- Do not use this massager outdoors.
- Avoid placing or operating this massager in direct sunlight or near a heating appliance, stove.



Safety Instructions

c) User precautions

- Make sure that this product is far away from any hot surfaces.
- Please consult your doctor before use for those who have the following diseases:
 - Those who have heart disease, malignant tumor, spinal scoliosis, osteoporosis, etc.
 - Those who are pregnant or having a menstrual period.
 - Those who have a physical discomfort, fever, a swelling or inflammation, bruises, allergies, etc.
 - Those who are warned by the doctor not to do any massage to avoid injury or physical discomforts such as blood clots (thrombosis), severe aneurysm, acute venous tumor, all kinds of skin inflammation, infectious skin disease (including subcutaneous tissue inflammation), etc.
 - Warnings: Do not use the massager together with the following medical instruments.
 - 1) Those who are using a pacemaker or other implantable medical equipment.
 - 2) Those who are using an artificial heart.
 - 3) Those who are wearing an electrocardiograph for similar medical equipment.

Otherwise it will cause malfunction for those medical equipment, putting the user's life in danger.

d) Precautions for power supply

- Do not turn on the switch when your hands are wet.
- Do not immerse in or spray water or liquid on the control power switch.

e) Cord/Plug Precautions



- Do not connect or remove the plug with wet hands. Otherwise you will suffer an electric shock or a product malfunction.
- Do not pull the wires when you pull out the power plug. Please hold the plug itself.
- As the default operating time is 15 minutes, all the functions will stop working after 15 minutes. Turn off the main ON/OFF switch when not in use
- Keep the cord away from hot surfaces.
- Do not place the power plug under the product or any heavy items.



Safety Instructions

- Do not wind the power plug around the product lest it should be damaged and cause an electric shock or fire.
- Do not operate this product if it has a damaged cord or plug.
- Do not use this product if the power socket is loose.
- Do not carry this product by its supply cord or use the cord as a handle.
- When the power plug is damaged, please call the service centre or an authorized technical person for the necessary check and maintenance.

Attention

- 
- 
- Do not fall asleep during massage.
 - Do not use this product while you are drunk or physically uncomfortable.
 - Don't stand on the product or put a heavy weight on it.
 - Do not use this product for more than 30 minutes.
 - Do not use this product if the cloth cover is worn out.
 - Do not use this product within an hour before or after a meal.
 - When you are using the product at a low room temperature, do not suddenly use the heat function. You can adjust the room temperature to normal room temperature, before starting the heat function.
 - When moving this product from a low temperature storage place to a warmer setting, it may cause malfunction due to water vapor gathered in the components. Set the product in a normal room temperature for one hour before using it.
 - Do not use this product if you find any components damaged or the product in an abnormal condition.
 - When current interruption occurs during your massage, try to avoid further damage due to sudden power restoration.
 - Stop using the product if there is thunder and lightning.



Warranty Claims


1. Warranty does not cover accessories and upholstery.
2. Warranty is not transferable.
3. This warranty is effective only if the product is purchased from OGAWA.
4. Proof of purchase (original receipt) is required for all warranty repairs.
5. All implied warranties, including but not limited to these implied warranties of fitness and merchantability, are limited to the duration stated in the warranty policy.
6. Damage due to misuse, improper treatment and unauthorized modification and repair are not covered by this warranty.
7. Warranty does not cover accessories and attachments which do not belong to the massage unit.
8. Warranty is not effective to rental, business, commercial, institutional or other non-residential users.
9. All services covered by this warranty must be approved by OGAWA and repaired by authorized technicians only.
10. If replacement parts for defective materials are not available, OGAWA reserves the right to make substitution in lieu of repair or replacement.



The instructions state that

1. the appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction
2. children being supervised not to play with the appliance

Product Parts



Product Features And Operation Illustrations



CAUTION: Product have heating surface, attention to people who not not sensitive to heat

Operation Instruction



POWER

Press to turn ON message function. Press again to turn OFF message function.
Remark: Press this to turn OFF any message function



MASSAGE SPEED

Press this button to change the massage speed: Low > Medium > High > OFF



AIR INTENSITY

Press this button to change the air intensity: Low > Medium > High > OFF



VIBRATION LEVEL

Press this button to change the vibration level: Low > Medium > High > OFF



HEAT

Press this button to change the heat temperature: Low (blue LED) > High (red LED) > OFF

Product Operation Guide

a) Instructions before use


Please store this product in a dry place, do not expose the product to direct sunlight. Put the carpet under the product to minimize the working noise.

b) How to use it

This product use only the 12V DC, 2.0A current. Please make sure you are using correct adaptor


parameter.

- Connect the AC power cord to the socket.
- Turn on the power switch at the back of product to "I", when the red light is on, the yellow light on control panel blinks, the product is in standby mode.



Do not insert or remove the plug with a wet hand

- Place your legs in the product, before pressing the switch key on screen. When the blue light is on, the other functions will follow. According to the indicators on the control panel, you can choose different massage modes.
- When you start the massage, the product will be countdown in 15minutes. After 15 minutes, the massage function is turned off, and it will recover to standby mode.



Do not put your hands inside the cloth cover.


Product Maintenance

a) Storage

- Please store it in the packing carton, and put in a safe, dry, well-ventilated, and shaded place.
- Do not twist the power plug.
- Do not hang the power wire and pull the product.
- Avoid sharp items from destroying the surface of the product.
- Please don't store the machine under direct sunlight or in places of high temperature.

b) Clean

- Before cleaning, make sure that the power cord is unplugged from the electrical outlet and that the machine is completely cool.
- Use a damp cloth to clean the product. Ensure the product is completely dry before reuse.



*Attention

- Make sure not to use benzene or thinner and other corrosive detergents to clean the product.

c) Maintenance

- Keep the product clean and store in a dry environment.
- When the product is not in use for a long time, please put a dustproof cover on the product.

Troubleshooting

If you meet the following problems, please referring to the following solutions. If the product is still malfunctioning or doesn't work, please send the product to our service centre or an authorized technician for the necessary checks and repair.

| Conditions | Possible reason | Solutions |
|-----------------------|---|---|
| It doesn't work | <ol style="list-style-type: none">1. Plug isn't connected correctly to the socket. | <ol style="list-style-type: none">1. Push the plug firmly into the socket. |
| Stop working suddenly | <ol style="list-style-type: none">1. The power switch is off.2. Massage time is over 15 minutes.3. If it is working for a long time, the motor will be protected against overheating.4. If you put heavy pressure on the rollers and the rollers do not work well. | <ol style="list-style-type: none">1. Check that the power plug is connected well.2. Restart the power supply switch.3. After the product is cooled down, please restart the ON/OFF power.4. Switch off the power supply, and turn it on again. |

Product Specifications

| | |
|-----------------------------|---------------------|
| Product name | REJOY Foot Massager |
| Model number of the product | OF1733 |
| Input voltage | 12V DC, 3.0A |
| Power consumption | 30W |
| Timer | 15 minutes |

Contact Us



MALAYSIA
Healthy World Lifestyle Sdn Bhd
No. 22 Jalan Anggerik Mokara 31/47
Kota Kemuning, 40460 Shah Alam
Selangor Darul Ehsan, Malaysia
Tel : +1800-88-4688
Fax: +603-5121 4386



HONG KONG, CHINA
OGAWA Health Care International(HK) Ltd
31/F, YHC tower, 1 Sheung Yuet Road
Kowloon Bay
Kowloon
Hong Kong
Tel: +852 3465 6262
Fax: +852 2410 0119



SINGAPORE
OGAWA Health-Care Pte Ltd
27/Tampines Industrial Avenue 5,
T5@Tampines
Singapore 528623
Tel: +065-6846 8588
Fax: +065-6846 7677



VIETNAM
OGAWA Vietnam Co Ltd
2nd floor, Petroland Tower,
12 Tan Trao, Tan Phu ward
District 7
Ho Chi Minh
Tel: +848 54133 222/54133 223
Fax: +848 5416 1736





PHILIPPINES
O-Healthcare Solution Phil. Inc.
2303, 4th Floor, G&A Building,
Chino Roces Avenue Extension,
Makati City, Philippines
Tel : +632 889 0676 / +632 844 6851
Fax: +632 812 0421



目录

| | |
|--------|----|
| 安全说明 | 15 |
| 保修权限 | 18 |
| 产品部件 | 19 |
| 产品操作说明 | 20 |
| 产品保养 | 23 |
| 疑难解答 | 24 |
| 产品规格 | 25 |
| 联络我们 | 26 |



感谢您购买 足疗机，使用前请仔细阅读操作手册，并特别注意安全事项，以便正确操作和使用本产品。

本手册提供使用者安全及有效的操作方式，请在阅毕后妥为收藏，以便日后参考查询。

安全说明

a) 重要安全事项说明

- 为确保安全及正确使用产品，使用前请务必详细参阅操作手册。
- 请务必依照本操作手册内的产品用途使用本产品。
- 清洁产品前，请将电源插头从插座中拔除。
- 请务必谨慎使用温热功能，以避免可能会导致严重灼伤。请勿用于感觉迟钝和过于敏感的皮肤。切勿让儿童或者身心功能障碍者自行使用温热功能，操作不当可能存在危险。
- 为避免因过热而导致走火、触电、或造成伤害，请勿将产品置于枕头或毯子下操作。
- 请勿覆盖使用，以免造成马达温度过高而导致故障或损坏。
- 如在按摩进行中感到不适，请立即停止按摩。
- 下列状况发生时，切勿使用本产品：电源线或电源插头损坏；操作不正常；曾倾倒或者损伤；曾浸入水中或其他液体。请联系维修服务中心进行检查和维修。
- 请勿将物品插入或者掉落产品的任何开口中。
- 若想切断电源，请将所有的操作控制关闭后，将电源插头从插座中拔除。
- 本产品不能作为自我诊断或治疗之用，如需要诊断或治疗，应由专业医疗人员处理。

b) 使用环境

- 请勿在潮湿或过多灰尘的环境下使用产品，以免产品发生故障。
- 请勿在室温高于40°C的环境下使用本产品。
- 请勿将产品放置户外。
- 请勿将产品置放于电热器、炉具附近或者阳光直射处。

安全说明

c) 操作安全

- 确保本产品远离发热表面及区域。
- 此产品不适宜以下人士使用：
 - 心脏病患者、恶性肿瘤患者、脊椎侧弯或异常、骨质疏松症等。
 - 孕妇或经期女性。
 - 身体不适者，发烧、身体有红肿或发炎、瘀青、过敏等。
 - 医生叮嘱禁止按摩的人请勿使用，以免导致事故或身体不适如血栓（栓塞）病症；重度动脉瘤；急性静脉瘤；各种皮肤炎；皮肤感染病症（含皮下组织炎症）等。
 - 绝对不能与以下医疗电子仪器一起使用
 - 1) 心脏起搏器等植入式医疗电子仪器。
 - 2) 人工心脏等用来维持生命的医疗电子仪器。
 - 3) 心电图机等佩戴式医疗电子仪器。

否则可能会导致上述医疗电子仪器产生误动作，可能会危及生命。

d) 开关注意事项

- 请勿用湿手操作控制开关。
- 请勿让控制开关接触水等液体。

e) 使用电源插头及电源线须知

- 请勿用潮湿的双手安插或者拔除电源插头，以免触电或者导致机件故障。
- 拔出电源插头时，请握住插头本身，切勿拉扯电线。
- 虽然15分钟自动定时功能会自动停止产品运作，仍请每次使用完毕后，务必将主电源切断。
- 电源线务必与加热表面保持安全距离。
- 请勿将电源线置于产品或任何重物之下。
- 请勿将电源线缠绕于产品上，以免电源线受损而导致触电或者电线走火。
- 当电源线或者电源插头损坏时，切勿继续使用产品。
- 电源插座有松动的状况时，请勿使用产品。
- 请勿以拉扯电源线方式移动产品，或将电源线当握把使用。
- 当电源线损坏时，必须由服务中心或经授权技术人员进行检查及维修。

安全说明

注意


- 请勿在产品操作时入睡。
- 请勿在酒醉或身体不适时使用本产品。
- 请勿站在产品上或重物施压。
- 连续使用本产品时间请勿超过三十分钟。
- 若产品的布套已经破损，请勿使用。
- 请勿在进食前后一小时使用，以免造成反效果。
- 在偏低室温中使用产品时，切勿骤然使用温热功能，建议将温度逐渐调至正常范围后再使用。
- 若是将产品由低温储存处移至温暖环境使用时，可能会因为机件内水汽聚集而影响产品正常运作，甚至造成机件故障。建议移动后，先将产品在正常室温放置1小时后再开始使用。
- 使用中察觉任何机件故障或不正常状况，请立即停止使用。
- 若在使用中发生电流中断的状况，因注意避免因电力突然恢复而造成使用者受伤。
- 雷电情形发生时，不宜使用本产品。



保修权限

1. 本保修权限不可转让。
2. 本保修服务仅对在 OGAWA 购买的产品有效。
3. 当要求保修服务时，请出示购买证明（正本收据）。
4. 所有保修项目，包括但不限于这些健身及适销性的保修项目有效期限需视保修政策而定。
5. 因错误使用、处理不当以及未经授权私自改装和维修产品而导致的损坏，不属于保修范围。
6. 此保修范围不包括不属于产品本身的附件。
7. 此保修范围不适用于租赁、交易、商业、机构或其他非住宅用户。
8. 此保修范围内所涉及的维修服务需经过 OGAWA 授权，且必须由授权的技术人员维修。
9. 若需更换的维修附件缺货，OGAWA 有权采用替代配件进行维修。

产品部件



产品操作说明



注意

◆ 器具具有发热表面，对热不敏感的人使用时必须注意。

按键说明



待机键

接通电源后灯闪烁，按此键开机灯常亮，并同时开启滚轮、气压、振动及热敷按摩功能；
再按一次，关机。

注：在任何运行模式下，按此键可关闭所有功能。



揉捏按摩键

开机状态下，按此键调节滚轮速度：低=低速滚轮，中=中速滚轮，高=高速滚轮，灯灭滚轮功能关闭。



气压按摩键

开机状态下，按此键调节气压强度：低=低强度气压，中=中强度气压，高=高强度气压，灯灭气压功能关闭。



振动按摩键

开机状态下，按此键调节振动频率：低=低频振动，中=中频振动，高=高频振动，灯灭振动功能关闭。



热敷键

开机状态下，按此键调节热敷温度：蓝灯亮，低档；红灯亮，高档；灯灭加热功能关闭。

产品操作说明



a) 使用前准备

请将本产品置于干燥、阳光不能长期照射的地方。
为减少机器工作时的噪音，可在本产品下铺上地毯。
确保产品放置位置安稳舒适。

b) 使用方法

本产品仅使用于 12V DC, 2.0A 的电源，
请事先检测您是否用对的适配器。

- 将交流电源插头接至电源插座。
- 此时控制面板上下开关键红灯闪烁，产品进行待机状态。





产品操作说明

- 将双脚放入产品，按下控制面板开关键，红灯指示;其它按键功能响应。依控制面板指示，选择按摩模式。
- 使用产品倒计时15分钟结束后，按摩功能停止，恢复待机状态。
- 产品处于待机状态时，按下总电源开关“0”，电源切断。


产品保养

a) 贮藏

- 不使用时，请将产品放入包装盒中，并放置于安全、干燥、通风阳剧、阴凉处。
- 切勿扭曲电源线。
- 切勿使用电源线拖拽产品。
- 避免尖状物刮破产品表面。
- 请勿将产品放置在阳光直射或高温处。

b) 清洁

- 清洁之前，确认总电源开关已关闭，并拔出电源插头。
- 请使用干布清洁产品表面。
- 可拆洗布套可按正常布料洗涤方式清洗。



*注意

- 切勿使用具有腐蚀性的清洁剂，如苯或稀释剂来清洁产品。

c) 保养

- 保持产品清洁并远离高湿度的场所。
- 如果长时间不使用本产品，请用防尘罩(请自行购买)套住产品，防止落入灰尘。

疑难解答

若在使用此产品时遇到问题，请参考下列几点提示及可能解决方式。若此产品仍处于故障状态请将产品送至服务中心或经授权技术人员进行检查及维修。

| 故障 | 原因 | 处理方法 |
|---------|--|---|
| 无法开机。 | <ol style="list-style-type: none">1. 未通电2. 面板开关键未开启3. | <ol style="list-style-type: none">1. 接入电源或检查否连接良好2. 开启面板开关键3. |
| 突然停止操作。 | <ol style="list-style-type: none">1. 断电。2. 按摩时间超过15分钟。3. 连续使用时间过长，产品过热保护。4. 施力过大，按摩球堵转。 | <ol style="list-style-type: none">1. 检查电源接口是否接好。2. 重新开启开关键。3. 产品冷却后重新开启开关键。4. 重新启动开关键。 |

产品规格

| | |
|------|---------------------|
| 产品名称 | REJOY Foot Massager |
| 产品型号 | OF1733 |
| 输入电压 | 12V DC, 3.0A |
| 功率 | 30W |
| 定时 | 15 分钟 |

联络我们

马来西亚



Healthy World Lifestyle Sdn Bhd
No. 22 Jalan Anggerik Mokara 31/47
Kota Kemuning, 40460 Shah Alam
Selangor Darul Ehsan, Malaysia
Tel: +1800-88-4688
Fax: +603-5121 4386

新加坡



OGAWA Health-Care Pte Ltd
27/Tampines Industrial Avenue 5,
T5@Tampines
Singapore 528623
Tel: +065-6846 8588
Fax: +065-6846 7677

菲律宾



O-Healthcare Solution Phil. Inc.
2303, 4th Floor, G&A Building,
Chino Roces Avenue Extension,
Makati City, Philippines
Tel : +632 889 0676 / +632 844 6851
Fax: +632 812 0421

中国香港



OGAWA Health Care International(HK) Ltd
31/F,YHC tower,1Sheung Yuet Road
Kowloon Bay
Kowloon
Hong Kong
Tel:+852 3465 6262
Fax:+852 2410 0119

越南



OGAWA Vietnam Co Ltd
2nd floor,Petroland Tower,
12 Tan Trao, Tan Phu ward
District 7
Ho Chi Minh
Tel: +848 54133 222/54133 223
Fax: +848 5416 1736



Ogawa is grateful
to have received
these awards:



Ogawa Wellness Hubs : Malaysia . Singapore . Vietnam . Philippines . Indonesia . Myanmar . India . China
Hong Kong . TaiWan . Turkey . Pakistan . Mauritius . Russia . France . Canada
Thailand . Korea . Australia . Dubai . K.S.A . Nigeria . Egypt . Lebanon . Denmark
Sweden . U.S.A

